

# *Index*

---

## A

**About InstantImager window, R42**

**Acquisition, GS39**

- accessible functions during, *GS51*
- image file specification, *GS41*
- owner specification, *GS42*
- protocol specification, *GS40*
- start, *GS43*
- stop, *GS44*
- subject, *GS42*
- system messages, *GS43*
- update, *GS46, R384*

**Acquisition continue parameters window, GS45, R43**

**Acquisition start parameters window, GS39, GS41, GS43, R44**

**Add standard to list window, R46, R259**

**Annotate image, GS67**

- create arrow, *GS72*
- draw line, *GS68*
- erase annotation, *GS68*
- hide annotation, *GS74, GS87*
- move annotation, *GS73*
- write comment, *GS69*

**Applications, R6**

**Arrow annotation, GS72**

- edit annotation, *GS72*

**Auto/local rescale, GS61**

## B

**Background**

- cells, *R216*
- create background region, *R217*
- regions, *R215*
- subtraction, *R215*

**Backing up images, R388**

## C

**Calibration, GS16, R374, R391**

- ambient temperature, *R391*
- atmospheric temperature, *R391*
- calibration source, *R394*
- channel sum threshold, *R391*
- detector setting, *R391*
- frequency, *R374, R392*
- optimal channel noise, *R391*
- optimal group threshold level, *R391*
- procedure, *R393*

**Colors, GS60**

- annotation, *R382*
- helpline, *R382*
- template, *R382*

**Config.sys, R390**

- d000–dfff segment of memory, *R390*
- memory manager, *R390*

**Conventions, R3, R4**

**Counting method, GS34**

- count indefinitely, *GS34*
- preset number of counts, *GS36*
- preset number of minutes, *GS35*
- specify cursor coordinates, *GS36*

**Create template window, GS84, GS89, R48, R207**

**Crop image, R170**

**Cumulative time series, R75, R170, R200**

**Custom palette window, GS64, R50**

## D

**Default lane length, R245**

**Deleting images, R381**

**Detector, GS3, R6, R172**

dimensions, R172  
operation, R172

**Disk allocation, R173**

**Display range, GS56**

auto/local rescale, GS61  
colors, GS60  
gray, GS60  
inverted, GS61  
linear relationship, GS60, GS64  
logarithmic relationship, GS60, GS64  
manual rescale, GS61  
sigmoidal relationship, GS64

**Display window, GS58, R52**

**Dynamic range, R173**

## E

**Edit acquisition protocol file window, GS33, GS34, GS38, R55**

**Edit arrow window, GS72, R59**

**Edit current protocol window, GS40, R61**

**Edit group of regions window, R64**

**Edit lane points window, R68, R265**

**Edit lane window, R317**

integration limits, R320  
lane label, R319  
origin and front, R318  
profile region, R318  
region label, R319  
region type, R320

**Edit region window, R71**

**Edit time series, R36, R45, R63, R74**

**Editing cues, R174**

**Electrical requirements, R12**

**Electronic autoradiography, R6**

**Enable time series, R75, R174**

**Environmental requirements, R12**

ambient temperature, R12  
relative humidity, R12

**Erase annotation, GS68**

**Export profile data window, R290**

**Export profile display window, R293**

## F

**File export window, R76**

**Find peaks & bkgd window, R310, R312**

accept results, R314  
background points, R312  
find background process, R312  
peak sensitivity, R313  
preview results, R313  
smoothing, R312

**Find regions window, R79, R232**

**Font window, GS71, R83**

## G

**Gas**

and air in system, R374  
hazard, R375  
pressure, R13, R375  
replace gas bottle at 100psi, R374  
requirement, R13, R375

**Graphical user interface, GS10, R17**

**Gray, GS60**

**Grid report options window, GS97, R86**

**Grid template, edit graphically, GS95**

**Grid template parameters window, GS89, R89, R208**

**Grid template report, GS106**

**Grids, GS89, R207**

create, GS92  
edit graphically, GS95, R212  
edit numerically, GS97, R215  
grid template report, GS100, R347  
move/copy, GS95, R212  
reporting, GS97, R343  
resize, GS96, R213  
resize cell, GS96, R214  
rotate, GS95, R213  
select, GS95, R212

## H

### **Hazard, R376**

electrical, R376  
mechanical, R376

### **Hide annotation, GS74, GS87**

### **High memory, R390**

config.sys, R390  
d000–dfff segment of memory, R390  
dsp, R390  
instrument performance, R390

### **High resolution, R178**

### **Histogram, GS56**

## I

### **Image**

.ana file, GS50  
.img file, GS50  
acquisition, GS39  
backing up, R388  
crop, R170  
deleting, R381  
intensity, GS56, GS58  
optimal display range, GS56  
print, R335  
print selected region, R339  
printed image, R340  
scaling image data, GS57  
store, GS50  
transform, R202  
viewing, R380

### **Image information window, R92**

### **Imager user utility, R377**

### **Imager users window, R94, R378**

### **Individual time series, R75, R179, R200**

### **Installing software, R388**

config.sys, R390  
dsp, R390  
high memory, R390  
memory manager, R390

### **Instance, R179**

### **InstantImager, GS2, R180**

applications, GS2, R6  
autoradiography, GS2, R6  
basic instrument use, GS16  
calibrating, GS16  
concept, R7  
detector, GS2  
instance, R179  
menus, R27  
radioactive label, R7  
sample analysis, R7  
software, R24  
starting, GS7, R24, R179  
system hardware, GS3  
troubleshooting, R367

### **InstantImager window, GS7, R24, R97**

### **Instrument specifications, R12**

electrical requirements, R12  
environmental requirements, R12  
physical dimensions, R12

### **Interval, R75**

### **Inverted, GS61**

## L

### **Lane group report options**

(profile regions) window, R323

### **Lane group report options window, R100**

### **Lane point, R182**

### **Lane template parameters window, R104, R240**

**Lanes, R239**

- background region, R253
- band, R252
- create, R240
- curve individual lane, R247
- default length, R245
- delete region, R255
- drawing tools, R250
- edit graphically, R244
- edit individual lanes graphically, R246
- edit lane points, R265
- edit region, R254
- elliptical region, R251
- irregular region, R251
- labeling, R255
- lane tag, R241
- lane template report, R362
- length, R245
- molecular weight standard curve, R261
- molecular weights, R257
- move individual lane, R246
- move/copy, R244
- move/copy region, R254
- profile region, R252
- profiling, R256
- rectangular region, R251
- reporting, R357
- resize individual lane width, R247
- resize length, R245
- resize region, R255
- resize width/height, R244
- rotate, R245
- select, R248
- select region, R254
- standard curve parameters, R262
- standard region, R253
- template tag, R241
- unknown region, R253

**Lanes (profile 1D analysis), R317**

- integration limits, R320
- lane label, R319
- origin and front, R318
- profile region, R318
- region label, R319
- region type, R320
- reporting lane profile, R323

**LED lights, GS3, R8****Line segment annotation, GS68****Linear relationship, GS60****Load protocol window, R107****Load template window, GS81, R109****Logarithmic relationship, GS60**

## M

**Magnify image, GS54****Manual rescale, GS61****Mark standard window, R111, R257****Maximum image intensity, GS58**

- adjusting, GS59

**Memory manager, R390**

- config.sys, R390
- d000-dfff segment of memory, R390
- dsp, R390
- instrument performance, R390

**Menus, R27**

- acquisition, R36
- analysis, R34
- file, R27
- system, R37
- tasks, R38
- transform, R30
- view, R32

**Menus (profile 1D analysis), R279**

- analysis, R286
- file, R282
- tasks, R289
- view, R284
- window, R288

**Messages, R369****Minimum image intensity, GS58**

- adjusting, GS59

**Molecular weight, R257**

- add standard to list, R259
- assign to lane, R257
- calculations, R263
- change individually, R266
- change using list, R267
- determine, R257
- molecular weight standard curve, R261
- select standard curve parameters, R262

**Molecular weight (profile 1D analysis), R321**

- change individually, R322
- change using list, R321
- default list, R322
- profile region, R321
- standard file, R322
- units, R322

**Molecular weight standard curve window, R113, R261**

**Mouse, GS13, R20**

clicking, GS14, R21  
double clicking, GS14, R21  
dragging, GS14, R21  
mouse buttons, GS13, R21  
moving on work surface, GS13, R20

**Move annotation, GS73**

## O

**On/Off switch, GS3****Open image window, R114****Overlaid plots window, R306****Owner, R187**

## P

**Password**

protection, R387  
system password, R386  
user access, R387

**Peak tags window, R301**

activity, R302  
horizontal orientation, R303  
no tag, R302  
peak label, R301  
peak number, R301  
vertical orientation, R303, R304

**Physical dimensions, R12****Pixel, R188**

maximum counts, GS56

**Print profile display window, R293****Print setup window, GS109****Print window, R116, R335****Problems, troubleshooting, R367****Profile, R256**

adjust template, R256

**Profile (1D) analysis, R269**

background profile, R316  
delete background point, R316  
delete region, R315  
interface with 2D image, R269  
move background point, R316  
move region, R315  
region, R315  
resize region, R315  
select background point, R316

**Profile axes window, R298**

activity units, R300  
distance units, R299

**Profile display mode, R306****Profile frame window, R270**

template bar, R279  
toolbox, R275

**Profile window, R271**

activity, R273  
distance, R274  
lane selection, R272  
profile bitmap, R273  
profile display, R272

**Protocol**

comment, GS32, GS34  
counting method, GS32, GS34  
default status, GS32, GS37  
editing, GS38  
name, GS32, GS34  
preprogrammed, GS31  
template, GS32, GS37

**Protocol setup, GS31**

